

Fixed Width Banner Towers

1. Slide banners over crossbars and "L" brackets (fig. A).
2. Screw 3" standoff onto bases using flathead screw (fig. B-1).
3. Place crossbars in between standoff and upright and screw together (fig. B-2).
4. Screw top crossbars onto uprights using round knobs (fig. C).

Applicable Products:

SQ1, SQ2, SQ3, SQ4

