


L-Banner


Assembly Instruction

Parts List


Horizontal top and foot pole, each one piece:



High, low and mid support pole, each one piece



One piece base pole:



PVC sheet attached inside the top and foot pole:




L-Banner

Step by Step Assembly


Step 1

Take off the caps on the top and foot pole




Step 2

Take off the PVC sheet which is inside the poles, clip the finished picture and insert them together into the top and foot poles. Make sure it is the correct side.




Step 3

Then put on the caps




Step 4

Screw the base pole into the foot pole, tighten.




Step 5

Put the high support pole into the connectors marked 7 and 8, tighten. Now the high and low pole should be one completed pole.



Step 6


Put the completed pole into the connectors on top and foot pole respectively. That's a finished display.




L-Banner Graphic Assembly



1. Locate top and bottom horizontal.
Release gripper as indicated in photo



2. Remove end cap



3. Slide Graphic into top/ bottom bar



4. Starting in the center of graphic, close v-gripper and work gripper closed from center to end on each side